

**IMPORTANT:** Failure to properly install Designer DripEdge® may result in avoidable damage or serious injury. Always wear personal protective equipment when performing installation. Read through all instructions prior to installation. Please contact us at 800-328-5858 with any questions.

## Step #1:

Confirm the fit of the Designer DripEdge® with your pull-out waste can. The fit will vary depending on the size of the pull-out door and type of door you have.

## Step #2:

Thoroughly clean the top of the door where the Designer DripEdge® will be installed. Remove any external contents and dry the area completely.

## Step #3:

Using a rag and rubbing alcohol, wipe the installation area again to remove any remaining dust or residue. Wipe the area until it is dry.

## Step #4:

Peel the layer of plastic covering the pre-applied UHB tape on the Designer DripEdge® and attach the Designer DripEdge® to the pull-out door with the tape side on the top of the door.

*Be accurate in your placement. If the Designer DripEdge® is placed in an incorrect spot, remove promptly and replace in its proper position.*

## Step #5:

Hold the Designer DripEdge® tightly against the door and apply reasonable pressure for one minute.

*Failure to allow the tape to fully adhere to the door will compromise the integrity of the adhesive and may cause the Designer DripEdge® to loosen.*

## Step #6:

Clean the Designer DripEdge® with simple cleaning solutions and warm water routinely.

